


Model No.DC18RD TWO PORT MULTI FAST CHARGER



Model No.DC18RD TWO PORT MULTI FAST CHARGER

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/Old	Note1	Note2
001	804Y51-3	Indication label		1			
002	804Y52-1	Makita logo label		1			
003	455546-5	Terminal cover		2			
004	231474-6	Compression spring 4		4			
005	142845-1	Charger case complete		1			
005		INC. 6,7					
006	455402-9	Lens B		1			
007	455401-1	Lens A		1			
008	804Y47-4	Charging condition label		1			
009	266278-7	Flange tapping screw 3X10		2			
010	632E11-3	Terminal unit		2			
011	638499-5	Sirocco fan		2	*		
011-1	638499-5	Sirocco fan	O	2			
012	266764-8	Pan head tapping screw 3X8		4			
013	233194-8	Compression spring 4		2			
014	455399-2	Terminal base		2			
015	620120-0	Charging circuit		2			
015		INC. 16,17					
016	652800-0	Fuse		2			
017	647306-1	Varistor		2			
018	667708-5	Power supply cord		1			
019	620324-4	Filter circuit		1			
020A	620326-0	USB circuit		1	*		
020-1A	620412-7	USB circuit	<	1	*		
020-1	620412-7	USB circuit		1	*		
021	455398-4	Charger case cover		1			
022	455403-7	USB cover		1	*		
022-1	412817-3	Cover	<	1			
023	286255-3	Cap 13		4			
024	266426-8	Pan head tapping screw 4X20		6			
025	850E35-9	Name plate DC18RD		1			
A01	450128-8	Battery cover		4			
A02	197280-8	Battery BL1850B set		4	*		
A02D	197265-4	Battery BL1840B set		2	*		
A02	197422-4	Battery BL1860B set		4	*		
A02-1	197280-8	Battery BL1850B set	O	4			
A02-1D	197265-4	Battery BL1840B set	O	2			
A02-1	197422-4	Battery BL1860B set	O	4			
F01A	196933-6	Two port multi fast charger set DC18RD		1			
F01C	198458-6	Two port multi fast charger set DC18RD		1			
F01D	199481-4	Two port multi fast charger set DC18RD		1			
F01E	199482-2	Two port multi fast charger set DC18RD		1			
F01F	199483-0	Two port multi fast charger set DC18RD		1			

		C18RD					
F01G	199484-8	Two port multi fast charger set D C18RD		1			
F01H	199485-6	Two port multi fast charger set D C18RD		1			

Please state Parts No. when your order.

Print Date 11/17/2025